

ALSP basic



For determination of the density index

MOBILE TEST UNIT ALSP basic



• M O B I L

• FULLY ELECTRONIC





MOBILE TEST UNIT ALSP *basic*

APPLICATION

Metallic and non-metallic impurities, as well as hydrogen and oxides, may negatively affect the quality of an aluminium melt. By measuring the density index, it is possible to define, control and optimise the process of cleaning the melt, thereby improving the quality. In this way, the consistently high quality of the melt is assured and the reject rate effectively reduced.

Alloy AlSi7Mg0,3 Transfer ladle 400 kg



before impeller treatment vacuum sample 80 mbar, density index 13,64%



Mobile Test Unit ALSP basic is used to cast two melt samples to compare the densities: one sample solidifies in a defined vacuum of 80 mbar and the other sample at atmospheric pressure. The Electronic Density Index Balance MK 3000 **automatically** determines the specific density of the two samples according to the Archimedean principle and then the density index. The density index represents the percentage difference in density of the produced samples. The lower the density index, the cleaner the melt.

The design of ALSP basic allows for comfortable and efficient operation. The storage option for the supplied pouring ladle, as well as the water vessel embedded in the worktop for cooling the density samples prepared, are in the immediate vicinity of the operator. The balance stands loosely on the test unit and can optionally be placed elsewhere. The base of the unit offers three large storage compartments. Due to the smooth-running and heat-resistant castors, ALSP basic can be used flexibly at different casting stations or furnaces.

For more information, have a look at our website: www.mk-gmbh.de

PC SOFTWARE

- Saving of measurements
- Use of statistical process control (SPC)
- Analysis and assessment of data by means of various filters for the density index results
- Printable reports, export of results to MS Excel



SPECIAL FEATURES

- Long lifespan due to sturdy design
- Flexible use at different casting stations or furnaces
- · Process reliability through fully electronic control
 - Fully automatic control of vacuum to 80 mbar
 - Leakage indicator
 - Cycle counter
- Exact calculation of density to four decimal places (0,0000 g/cm³)
- Vessel for cooling density samples provided and shelf and storage space
- Capable of 100% calibration





PRODUCT EXTENSIONS

DROSS TEST



- Additional process for visual assessment of AI samples
- Pressure step 80 mbar (density index)
- Pressure step 30 mbar (Straube-Pfeiffer test for the assessment of the sample interior regarding hydrogen pores and oxides)
- Pressure step final 6±3 mbar (dross test to assess the sample surface regarding oxides and other impurities)



•

software

possible

TECHNICAL DATA

Design:

Mobile Test Unit of powder-coated hot galvanised steel sheet with three storage compartments, two fixed and two guiding wheels with brake

Dimensions: W 1.020 x D 700 x H 1.360 mm

Weight: approx. 110 kg

Power connection: Power cable with plug, 230 VAC, 1400 VA, 50-60 Hz, (115 VAC available on request)

Power consumption: 1400 VA

Vacuum pump: Oil-lubricated vacuum pump

Timer:

Electric short-period timer (1-99 min. or endless = 00) integrated in display

Vacuum chamber upper part: Incl. safety inspection glass

Weighing range: 3.000 g

Resolution: 0,01 g

Stabilising time: 3 sec.

Ambient temperature 10-50°C

DROSS TEST R&D



As Dross Test, but in total of 6 pressure steps:

- Pressure step 80/30/final mbar and
- 3 additional pressure steps in the range 140 final mbar (to be defined by the customer when placing the order)
- Key switch for interlocking the pressure steps

DUST PROTECTION CASE



- · Protection of the balance from contamination in the foundry
- Sturdy powder-coated construction of steel sheet with cable lead-through
- Cover with gas-pressure damping
- Large impact-proof plexiglas window
- Aluminium handle

PRODUCT LINE



Combi Package plus consists of 3VT plus incl. crucible pre-heating chamber and MK 3000 for determination of the density index



Thermal Analysis **TA 12.13** for determination of grain refinement and modification for the evaluation of mechanical properties



ALSP highline incl. crucible pre-heating chamber for determination of grain refinement and modification for the evaluation of mechanical properties

SHOCK ABSORBING PLATE

• Sturdy and convenient storage medium

directly at the workstation

and all intermediate results

Storage of up to 500 density index results

Transfer and analysis of data by supplied PC

Manual input of charge number and alloy type

Automatic recording of date, time, density index



- Protection of the balance by minimising external factors, such as shocks and vibrations
- Powder-coated steel swing plate with cut-out for cable routing
- 4 rubber feet
- Mounting holes for mk dust protection case

ABOUT US

We are a medium-sized, privately owned company established in 1984. We are located in the Westerwald region of Germany, about 100 km from Frankfurt, and design and build a range of high-quality aluminium melt test equipment for the foundry industry. Our products are the result of expertise and experience acquired over many years of close association with the aluminium industry. Besides manufacturing our equipment, we also provide customer services such as commissioning, maintenance and calibration of our test equipment, supported by our comprehensive spare parts inventory.

Our customers all over the world are served by us personally as well as by a team of representatives operating worldwide.

SERVICES

- Device demonstration
- Provision of rental units
- Commissioning and device instructions
- Staff training
- Maintenance and calibration service
- Spare and wear parts
- IT support







MANAGING DIRECTOR Nicolas Knoche

"Our vision is to become the worldwide leader in the design and manufacture of aluminium melt testing technology and in service to our customers."

Are you interested in technical consultancy and a demonstration on your premises? We look forward to your inquiry. Please check our website if a local representative is available in your country. Otherwise, please contact us directly for further support.

For more information, have a look at our website: www.mk-gmbh.de

CONTACT DATA

• mk Industrievertretungen GmbH Melt Measuring Technology Rödernhahn 1b 56459 Stahlhofen a.W., Germany +49 2663 82 10
+49 2663 34 31
information@mk-gmbh.de
www.mk-gmbh.de

